

Imaging Mac computer drives with the Talon[®] Ultimate

Table of Contents

1.0 Introduction	2
1.1 <i>Macs with the Apple T2 Security Chip</i>	2
1.2 <i>Apple File System (APFS)</i>	3
1.3 <i>Fusion Drives</i>	3
2.0 USB-C / Thunderbolt 3	4
2.1 <i>Only one USB-C / Thunderbolt 3 Port</i>	4
2.2 <i>Only Two USB-C / Thunderbolt 3 Ports</i>	4
2.3 <i>More than two USB-C / Thunderbolt 3 Ports</i>	5
2.3.1 <i>A USB-C Hub</i>	5
2.3.2 <i>Two USB-C Adapters</i>	5
3.0 USB 2.0 / USB 3.0	5
3.1 <i>Only One USB 2.0 / USB 3.0 Port</i>	6
3.2 <i>Two or More USB 2.0 / USB 3.0 Ports</i>	6
4.0 A Removable Drive	6
5.0 Thunderbolt / Thunderbolt 2	7
6.0 FireWire	7
7.0 Built-in Ethernet Port	7
Technical Support Information	7

Application Note

1.0 Introduction

This document provides guidance on the different ways to access a Mac computer's internal drive to be used as a Source drive on the Talon Ultimate. This document applies to the Mac line of computers.

Different Macs have different available ports. Depending on the ports available on the Mac, there may be more than one way to image a Mac drive. This document outlines the different ports available on Macs and the different ways (if possible) to image the drive depending on the available ports.

There are different ways a Mac can be imaged with the Talon Ultimate depending on the Mac computer. Most Macs have one or more of the following:

- USB-C / Thunderbolt 3
- USB 2.0 / USB 3.0
- A removable drive (HDD or SSD)
- Thunderbolt / Thunderbolt 2
- FireWire
- Built-in Ethernet

Depending on the Mac model, there may be multiple ways of imaging the drive.



Logiccube does not sell any of the adapters or hubs mentioned in this document. However, any third-party adapter or hub should work.

For the optimal speeds, anytime "Ethernet" is mentioned, it is recommended to use Gigabit Ethernet for optimal speeds.

1.1 Macs with the Apple T2 Security Chip

Mac computers with the Apple T2 Security Chip have added layers of security that may limit certain ways the drive can be imaged. At this time, there is only one way to image a Mac computer with the Apple T2 Security Chip when using the Talon Ultimate:

- **Use Targeted/Logical Imaging (File to File)** – The following are required for this method:
 - Access to the Mac's Operating System through a user account with Administrative rights.
 - The Mac and Talon Ultimate connected to the same network (or directly to each other with an Ethernet cable).

- Folders/directories on the Mac will need to be shared so the Talon Ultimate can access them.
- The shared folder(s) will need to be setup in the Manage Repositories screen on the Talon Ultimate.
- File to File imaging mode must be used. See Chapter 4 – Imaging, in the Talon Ultimate user’s manual.



Mac computers with the Apple T2 Security Chip can be imaged with the Falcon-NEO using Target Disk Mode.

For more information on the Falcon-NEO, please visit <https://www.logicube.com/shop/forensic-falcon-neo> or contact Logicube’s sales group at: sales@logicube.com.

1.2 Apple File System (APFS)

Mac computers with the Apple File System (APFS) can be imaged using any of the supported methods mentioned in this AppNote. However, Windows does not natively support APFS. Please check with your software analysis company to see if your analysis software supports APFS.

Drive contents with the APFS cannot be viewed using the and Talon Ultimate’s File Browser feature.

1.3 Fusion Drives

The type of drive used by the Mac is not dependent on any of the methods in this document. One exception is the Fusion drive. A fusion drive is a hybrid drive that combines a Hard Disk Drive (HDD) with a Solid State Drive (SSD) that is typically seen as a single drive on a Mac. Fusion drives can be imaged one of two ways:

- Using the USB Boot Client, or
- Using Target Disk Mode

When using the USB Boot Client, the Fusion drive will appear as two separate drives (the HDD and the SSD are shown as two separate drives). Fusion drives can still be imaged using the USB Boot Client but cannot be restored (using the Image to Drive method).

When using Target Disk Mode with Fusion drives, the Fusion drive will be seen as a single drive.

2.0 USB-C / Thunderbolt 3

For Macs that have one or more USB-C / Thunderbolt 3 ports, there are a few possible solutions that vary depending on how many USB-C / Thunderbolt 3 ports are available.

2.1 Only one USB-C / Thunderbolt 3 Port

Macs that have the USB-C / Thunderbolt 3 port typically require this port for charging. For Macs that have only one USB-C / Thunderbolt 3 port, the only recommended method is by using the following:

- **USB Boot Client** – Please see the following document for full details on the USB Boot Client: http://updates.logicube.com/manuals/USB_Boot_Client.pdf.
- **A USB-C hub** – The hub must have the following:
 - Power Delivery – So that the Mac can be plugged in to a power source.
 - At least one USB-A 2.0 or 3.0 port – Also for use with the USB Boot Client.
 - OPTIONAL: An Ethernet Port – For use with the USB Boot Client.



If the hub does not have an Ethernet port, a USB-A to Ethernet adapter is required.

2.2 Only Two USB-C / Thunderbolt 3 Ports

Since Macs typically require one of the USB-C ports for charging, if the Mac has two USB-C / Thunderbolt 3 ports, the USB Boot Client can be used along with a USB-C hub. Since there is a second USB-C / Thunderbolt 3 port, the hub required does not need to have power delivery.

Please see the following document for full details on the USB Boot Client: http://updates.logicube.com/manuals/USB_Boot_Client.pdf. The USB Boot Client is required along with the following:

- **A USB-C hub with the following:**
 - OPTIONAL: An Ethernet Port – For use with the USB Boot Client.



If the hub does not have an Ethernet port, a USB-A to Ethernet adapter is required.

- At least one USB-A 2.0 or 3.0 port – Also for use with the USB Boot Client. At least two ports are required if a USB-A to Ethernet adapter is used.

- OPTIONAL: Power Delivery – So that the Mac can be plugged in to a power source. This is not required since there is a second port available for power.

2.3 More than two USB-C / Thunderbolt 3 Ports

For Macs that have more than two USB-C / Thunderbolt 3 ports, the USB Boot Client still needs to be used, but there are different combinations of items that may work.

Please see the following document for full details on the USB Boot Client:

http://updates.logiccube.com/manuals/USB_Boot_Client.pdf. The USB Boot Client is required along with one of the following:

2.3.1 A USB-C Hub

A USB-C hub with the following:

- OPTIONAL: An Ethernet Port – For use with the USB Boot Client.



If the hub does not have an Ethernet port, one of the following is required:

- A USB-A to Ethernet adapter, or
 - A USB-C to Ethernet adapter (to connect directly to an on-board USB-C / Thunderbolt 3 port).
- At least one USB-A 2.0 or 3.0 port – Also for use with the USB Boot Client. At least two ports are required if a USB-A to Ethernet adapter is used.
 - OPTIONAL: Power Delivery – So that the Mac can be plugged in to a power source. This is not required since there are more than 2 ports available for power.

2.3.2 Two USB-C Adapters

Rather than using a USB-C hub, two separate adapters can be used:

- A USB-C to Ethernet adapter, and
- A USB-C (male) to USB-A (female) adapter (for use with the USB Boot Client).

3.0 USB 2.0 / USB 3.0

For Macs that have at least one USB 2.0 (Type A) or USB 3.0 (Type A) port, the USB Boot Client can be used. Target Disk Mode is not supported with USB 2.0 or USB 3.0 ports. Please see the following

document for full details on the USB Boot Client:
http://updates.logicube.com/manuals/USB_Boot_Client.pdf.

3.1 Only One USB 2.0 / USB 3.0 Port

If the Mac has only one USB 2.0 or 3.0 port, the The USB Boot Client is required along with one of the following:

A USB hub with the following:

- OPTIONAL: An Ethernet Port – For use with the USB Boot Client.



If the hub does not have an Ethernet port, a USB-A to Ethernet adapter is required.

- At least two or more USB 2.0 or 3.0 ports.

3.2 Two or More USB 2.0 / USB 3.0 Ports

If the Mac has two or more USB 2.0 or 3.0 ports, the USB Boot Client is required along with the a USB-A to Ethernet adapter.

4.0 A Removable Drive

Some Macs have drives that can be removed. These drives can be Hard Disk Drives or Solid State Drives and the drive's connector can vary. Some may have standard SATA connectors while others have proprietary connectors.

The Talon Ultimate supports drives with standard SATA connectors using the SAS/SATA cables that are included with the Talon Ultimate.

Some drives that do not have the standard SATA connector, may still work with the Talon Ultimate, but may require additional third-party adapters, while other drives that do not have the standard SATA connector may not work.

Contact Logicube Technical support (support@logicube.com) to see if a third party adapter might work. When contacting Tech Support, please include the following information:

- A clear picture of the entire drive (front and back) which should include the connector pins.
- The Mac Model Identifier. For example, as a reference, please see the following pages:
 - MacBook (<https://support.apple.com/en-us/HT201608>)
 - MacBook Pro (<https://support.apple.com/en-us/HT201300>)
 - MacBook Air (<https://support.apple.com/en-us/HT201862>)

Application Note

5.0 Thunderbolt / Thunderbolt 2

For Macs that have the older Thunderbolt or Thunderbolt 2 ports, Target Disk Mode can be used along with a Thunderbolt-to-FireWire adapter (to connect from the Mac's Thunderbolt port to the Talon Ultimate's FireWire port).



For the Talon Ultimate, the FireWire option must be enabled. The FireWire option is enabled with software v2.0 or higher.

6.0 FireWire

For Macs that have a FireWire port, Target Disk Mode can be used along with a FireWire cable that will fit the Mac computer and the Talon Ultimate.



For the Talon Ultimate, the FireWire option must be enabled. The FireWire option is enabled with software v2.0 or higher.

7.0 Built-in Ethernet Port

For Macs that have a built in Ethernet port, the USB Boot Client can be used as long as the Mac also has an available USB 2.0 or USB 3.0 port. Please see the following document for full details on the USB Boot Client: http://updates.logicube.com/manuals/USB_Boot_Client.pdf.

Technical Support Information

For further assistance please contact
Logicube Technical Support:
by phone: **(+1) 818.700.8488 8 a.m. – 5 p.m. PT, M-F**
(excluding US legal holidays)
or by email: techsupport@logicube.com

Apple, Mac, and FireWire are trademarks of Apple Inc., registered in the U.S. and other countries.

Thunderbolt, Thunderbolt 2, and Thunderbolt 3 are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries.